#### About:

- Scapy is a network packet manipulation and creation tool
- It allows you to send, sniff, dissect, and forge network packets
- This capability allows a user to probe, scan, or attack networks
- Primary usage and dependency is Python
  - This means that the previous two bullet points can be done automatically in a script
- When running Scapy, make sure to run as an administrator to have access to some functionalities like sending packets otherwise you will be blocked

#### **Building a Simple Packet:**

- Simple as stating >>> packetA=IP(ttl=10) defines a packet packetA that has a Time-To-Live of 10 hops ready to be sent on the IP layer.
- This packet can be built upon now that it has been defined
- For example, you can add a source flag and destination flag to it:


```
>>> packetA.src="127.0.0.1"
>>> packetA.dst="1.2.3.4"
```

Now when **packetA** is called in Scapy, this is the resulting output given:

```
>>> <IP ttl='10' src=127.0.0.1 dst=5.6.7.8 |>
```

# Sending a Packet:

- There are two functions available that allow you to send packets: send() and sendp()
- **send()** allows you to send packets on Layer 3, Network Layer, (while handling routing and Layer 2 for you), while **sendp()** sends packets on Layer 2, Data-Link Layer.
- For example: >>> send(IP(dst="1.2.3.4")/ICMP()) sends an ICMP ping over the network to the IP 1.2.3.4.
  - The / in the above code segment refers to a composition of two layers in which the lower layer (IP) can have one or more of its components overloaded by the upper layer (ICMP)
- Using Wireshark, we are able to capture the ping on the next page



## **Sending and Receiving Packets:**

- There are a couple functions that can be used for sending and receiving packets.
   sr(), sr1(), and srp()
- sr() sends a couple packets and receives the answer packets back along with unanswered packets
- **sr1()** is a variant of **sr()** that only sends one packet and gets back one answer packet. They are also both Layer 3 functions
- srp() is another variant of sr() that sends packets over Layer 2.
- For this example we will be using sr1() to send a ping over to slashdot.org:

```
>>> p = sr1(IP(dst="www.slashdot.org")/ICMP()/"This is a test echo
ping")
```

 We are able to capture the request and reply along with the data in Wireshark below:



```
Frame 2: 66 bytes on wire (528 bits), 66 bytes captured (528 bits) on interface enp0s3, id 0
▶ Ethernet II, Src: RealtekU_12:35:02 (52:54:00:12:35:02), Dst: PcsCompu_98:3d:cc (08:00:27:98:3d:cc)
▶ Internet Protocol Version 4, Src: 216.105.38.15, Dst: 10.0.2.15
▼ Internet Control Message Protocol
    Type: 0 (Echo (ping) reply)
    Code: 0
    Checksum: 0x93e1 [correct]
    [Checksum Status: Good]
    Identifier (BE): 0 (0x0000)
    Identifier (LE): 0 (0x0000)
    Sequence number (BE): 0 (0x0000)
    Sequence number (LE): 0 (0x0000)
    [Request frame: 1]
    [Response time: 99.904 ms]
  ▼ Data (24 bytes)
      [Length: 24]
                                                            . . ' . = . RT
                                                                    · · 5 · · · E
      08 00 27 98 3d cc 52 54 00 12 35 02 08 00 45 00
                                                           ·4···/· ·C·i&···
      00 34 85 fe 00 00 2f 01 fb 43 d8 69 26 0f 0a 00
      02 0f 00 00 93 e1 00 00 00 00 54 68 69
                                                                     · · This
0030
      73 20 61 20 74 65 73 74 20 <u>65 63 68 6f 20 70 69</u>
0040
```

#### **Establishing a HTTP Connection:**

- One small example we will go over is the automating the process of establishing a HTTP connection with Scapy
- There are two ways we can do this
  - Using HTTP()/HTTPRequest()
  - With the predefined function: http\_request()
- We first load the http layer with load\_layer("http")
- Then we use the following setup:


```
load_layer("http")

req = HTTP()/HTTPRequest(
    Accept_Encoding=b'gzip',
    Connection=b"keep-alive",
    Host=b'www.google.com'
    )

pkt = TCP_client.tcplink(HTTP, "www.google.com", 80)
ans = pkt.sr1(req)
pkt.close()
```

- This breakdown should look familiar from Computer Networks
- What this does is sends an HTTP SYN packet to <u>www.google.com</u>
- Once the Three-Way Handshake is established, the connection closes

This is shown below in the captured Wireshark packets below



• The other method of sending the same packet is by using the following:

```
load_layer("http")
http_request("www.google.com", "/", display=True)
```


- The use of http\_request() follows the same formatting as above and gets the same response, just shorter and more simple
- This method is quicker if you are not looking to set up your HTTP packet a specific way

## Sniffing:

- Captures packets being sent over the network to be analyzed (using tcpdump in this case with Ubuntu)
- Very useful as it provides a way to capture packets and analyze them
- There are a couple ways packets can be analyzed: show() and summary()
- Below are images of Wireshark and Scapy sniffing side-by-side to see the differences. The first is using show(), the other summary().

```
sniff(iface="enp0s3", prn=lambda x: x.show())
sniff(iface="enp0s3", prn=lambda x: x.summary())
```

- **iface** refers to the network that is to be analyzed. This is not required but used here as an example.
- prn is an argument that applies a function to be executed with each packet discovered
  - In this case, a lambda function that uses the show/summary function based on the packet input x



### **Controlled Sniffing Display:**

- There are a bunch of filters and methods that one can use to simplify what is seen from the sniffing similar to how Wireshark is done
- Below is an example of using sprintf() to format how data is displayed from each
  packet being sent. In this case, it prints the sending and receiving IP addresses
  along with any Raw data being sent in the packet and is then stored in the
  variable pkts

```
pkts = sniff(prn=lambda x:x.sprintf("{IP:%IP.src% ->
%IP.dst%\n}{Raw:%Raw.load%\n}"))

172.217.10.65 -> 10.0.2.15

172.217.10.65 -> 10.0.2.15
```

'\x16\x03\x03\x00\x80\x02\x00\x00|\x03\x03\xcbfWn\xa2\xd3\x97\x13\xff\x84\x96,\x9b\x1f7\x88\x08Q\xe7\x15\c\xb5\xaa\xb1\xe3\xa0m\\x88\x08Q\xe7\x15\c\xb5\xaa\xb1\xe3\xa0m\\x6\xf0\xc5\xb5\xaa\xb4\x9cp\xf0\xf0\xcc\xbf\xf0\xcc\xbf\xf0\xc2\xb5\xaa\xb4\x9cp\xf0\xf0\xcc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xf0\xsc\xbf\xsf\xad\xb0\xf9\xsc\xad\xb0\x11\x00\x004\x00)\x00\x00\x00\x003\x00\x1d\x00\x11\x\xdf\x00\xf9\xf0\x5\xce\x84v\x00\x1d\x00\xf0\x03\x04\x\xf0\xsf\xdc\xad\xb5\xce\x84v\x00+\x00\x02\x03\x04\x14\x03\x03\x00\x01\x17\x03\x03\x00\xc6\x12\xc4\x0b\xf1\xd6\xda\xb8\xb8\xb6\xcf\xe5\xfe\xda\xac\x1c\x08\xd1\x8a\xb0\x18\xbb\xcd\x11\x1b\x1a\x8a\x07\x6e\xf3\xe8\xef\x15\x9a\x87\x97\xec\xdc\xb4\xf6\xcf[\xad\x1a\xc0\xd4\xc7\xfa\xf6'

```
10.0.2.15 -> 172.217.10.65

10.0.2.15 -> 172.217.10.65

'\x14\x03\x03\x00\x01\x17\x03\x03\x005\xe5\xcf4<\r\x02w\x7f!\xcb#\xbb\x8f\xaf\x08\xd1--\xf6\xfe+i
\x99\x02g\xd6\x8f\r\x06m\xd4\xbb\x80\x0bd\xbe\xb6p)\xae\xa6\xe9\xd2A_\xa0<D\xe2RS;\x9d'

172.217.10.65 -> 10.0.2.15
```

10.0.2.15 -> 172.217.10.65
"\x17\x03\x03\x00\xa54G\x86m\x10\Tu\x08\xa2\x00\xc8^\xd5\x06\xa2\x0e~5\xe1EN!\x8c{\n\x94\xa1\xc5\x85\
xfdlh\x05\x8e\x1e\x10Z\x81\xde?P\xe6\xcc\xbe\n\xa0%\xbd:\x8fz\xfa'\xa8%9\xe1/\xf5b\xc2\xaeU\x08{%qg\x
a2<H\xe8\x01\xc1\xde\xf7X\x02\xe2h9A'X\x1b/\xe6\xbaa\xff\x94\xbb\xb1\x08\x8a\xbaN:\xe3U\xe5\xb6\xf0\x
c8\xe9gdiW\xdf\x1c!\xed\xbb\x8d\xf4\x9cJ\x0e\xa95\xcaN\*#V>\x8e\xecuyn\xd9\xfes\x9c3\xe2\xeb\xae\xbb\x
13V\x1f\xeb\xb3!\xf2 S3\xef\xe4r\xd9\xbe\xd4X\xfa\xd1!\t\xf0\xb8"

```
172.217.10.65 -> 10.0.2.15
```

• This can be stored/read for later use using the following lines:

```
wrpcap("Session1.cap",pkts)
pkts = rdpcap("Session1.cap")
```

Using hexdump(pkts) displays pkts data in a hexdump format like below

```
^C>>> hexdump(pkts)
0000
     1B 5B 30 6D 3C 1B 5B 30 6D 1B 5B 33 31 6D 1B 5B
                                                       .[0m<.[0m.[31m.[
0010
     31 6D 53 6E 69 66 66 65 64 1B 5B 30 6D 1B 5B 30
                                                       1mSniffed.[0m.[0
0020
     6D 3A 1B 5B 30 6D 20 1B 5B 33 34 6D 54 43 50 1B
                                                       m:.[0m .[34mTCP.
0030
     5B 30 6D 1B 5B 30 6D 3A 1B 5B 30 6D 1B 5B 33 35
                                                       [Om.[Om:.[Om.[35
0040
     6D 34 33 31 33 1B 5B 30 6D 20 1B 5B 33 34 6D 55
                                                       m4313.[0m .[34mU
0050
     44 50 1B 5B 30 6D 1B 5B 30 6D 3A 1B 5B 30 6D 1B
                                                       DP. [Om. [Om: . [Om.
0060
     5B 33 35 6D 33 38 35 36 1B 5B 30
                                      6D 20 1B 5B 33
                                                       [35m3856.[0m .[3
0070
     34 6D 49 43 4D 50 1B 5B 30 6D 1B 5B 30 6D 3A 1B
                                                       4mICMP.[Om.[Om:.
0080
     5B 30 6D 1B 5B 33 35 6D 36 35 1B 5B 30 6D 20 1B
                                                       [0m.[35m65.[0m .
0090
     5B 33 34 6D 4F 74 68 65 72 1B 5B 30 6D 1B 5B 30
                                                       [34mOther.[0m.[0
     6D 3A 1B 5B 30 6D 1B 5B 33 35 6D 31 38 1B 5B 30
00a0
                                                       m:.[0m.[35m18.[0
0000
     6D 1B 5B 30 6D 3E 1B 5B 30 6D
                                                       m. [0m>. [0m
```

### **Exporting to Wireshark:**

- Scapy has the capability of calling Wireshark when you want to use it to analyze packets stored in a variable
- Just simply use wireshark(pkts) and Scapy will open Wireshark up for you to analyze the packets

### **Using Scapy in Python Scripting:**

- Because Scapy is built on Python, everything being used above, can be used in a Python script as well
- All you need is to import from scapy.all import \* and you have access to everything you need
  - Do note that functionality like sending packets requires Sublime or whatever editor you're using to be run as administrator to work
- Below is an example of running the **sr1()** example in a Python script

```
File Edit Selection Find View Goto Tools Project Preferences Help
       ScapyLab.py
      from scapy.all import *
      p = srl(IP(dst="www.slashdot.org")/ICMP()/"Raw text being sent for testing")
  4 if p:
         p.show()
Begin emission:
.Finished sending 1 packets.
Received 2 packets, got 1 answers, remaining 0 packets
###[ IP ]###
 version = 4
 ihl
           = 5
           = 0x0
 tos
           = 59
 len
           = 53332
 id
 flags
           =
 frag
          = 0
 ttl
           = 47
           = icmp
 proto
 chksum = 0xb0e6
           = 216.105.38.15
 src
 dst
           = 10.0.2.15
  \options \
###[ ICMP ]###
    type
              = echo-reply
     code
              = 0
              = 0xca96
    chksum
              = 0x0
    id
    seq
              = 0x0
###[ Raw ]###
       load
              = 'Raw text being sent for testing'
[Finished in 0.9s]
```